

# A319/A320/A321 NORMAL PROCEDURES

---

## BEFORE START

Cockpit Preparation ..... COMPLETED  
 Gear Pins & Covers ..... REMOVED  
 Seat Belt Signs ..... ON/AUTO  
 ADIRS ..... NAV  
 Fuel Quantity ..... — KGS  
 Takeoff Data ..... — SET  
 Baro Reference ..... — SET

---

Windows/Doors ..... CLOSED  
 Beacon Lights ..... ON  
 APU Bleed ..... ON  
 Thrust Levers ..... IDLE  
 Parking Brake ..... AS REQUIRED

---

## AFTER START

Anti Ice ..... AS REQUIRED  
 ECAM Status ..... CHECKED  
 Pitch Trim ..... — SET  
 Rudder Trim ..... ZERO

---

## BEFORE TAKEOFF

Flight Controls ..... CHECKED  
 Flight Instruments ..... CHECKED  
 Takeoff Briefing ..... CONFIRMED  
 Flap Setting ..... — CONFIRMED  
 V1, VR, V2/FLX TEMP ..... —  
 ATC ..... SET  
 ECAM Memo ..... TO NO BLUE

---

Cabin Crew ..... ADVISED  
 Engine Mode Selector ..... AS REQUIRED  
 Packs ..... AS REQUIRED

---

## AFTER TAKEOFF/CLIMB

Landing Gear ..... UP  
 Flaps ..... UP  
 Packs ..... ON

---

Baro Reference ..... — SET

---



---

## APPROACH

Approach Briefing ..... CONFIRMED  
 ECAM Status ..... CHECKED  
 Seat Belt Signs ..... ON  
 Baro Reference ..... — SET  
 MDA/DH ..... — SET  
 Engine Mode Selector ..... AS REQUIRED

---

## LANDING

Cabin Crew ..... ADVISED  
 A/THR ..... SPEED/OFF  
 ECAM Memo ..... LDG NO BLUE

---

## AFTER LANDING

Flaps ..... UP  
 Spoilers ..... DOWN  
 APU ..... START  
 Weather Radar ..... OFF/STAND-BY

---

## PARKING

APU Bleed ..... ON  
 Engine Start Levers ..... CUTOFF  
 Seat Belt Signs ..... OFF  
 Exterior Lights ..... AS REQUIRED  
 Fuel Pumps ..... OFF  
 Parking Brake & Chocks ..... AS REQUIRED

---